



Nano

Coding Instructions Nano receiver



Art Series
Handset



TO CODE NEW REMOTES YOU NEED TO DO THE FOLLOWING:

- 0 Open motor cover (lid).
- c1 Press and hold **c1** button on the circuit board receiver
- 2 Press the button on the remote you want to program. Red LED will flash
- 3 Let go (release) both buttons
- 4 Test remote

DELETE CODING

- 1 Press and hold both **c1** for 10 seconds.
- 2 Please test your remote